

USER'S MANUAL




- Pls read the instruction manual carefully before using.

Notice

1. Don't clean by corrosive solvent.
2. Protect this device from shocks and abuse. Avoid brute force when operating the device.
3. Keep the device away from extremely hot or wet places.
4. The sequence of device setting: Time setting → Calendar setting.
5. Please adjust the calendar orderly. The sequence of Calendar setting: week → date → month.
6. Under normal mode, week, date or month makes two signals with each flip when turning one page.

Appearance



Front View

Back view

Part A ---Functions

- A1. Hour**
- A3. Second**
- A5. Month**
- A7. Week**

- A2. Minute**
- A4. Year**
- A6. Date**

Part B--buttons

- B1. Month switch**
- B3. Week turning on/off**
- B5. Time adjustor**

- B2. Date switch**
- B4. Device power on/off**


Part C—Structure

- C1. Battery compartment for time**
- C3. Wall mount hole**

- C2. Battery compartment for calendar**
- C4. Numbers compartment**

I. Time setting

1. The time setting is the same as that of common quartz clock.
2. Move the minute hand with clockwise slowly, the first signal rings around 11:30, which indicates calendar is ready to run; after 2~3 seconds, please continue to move it. The second signal rings around 12:00, which indicates calendar runs. Calendar runs twice every day (When pushing the power button to “OFF” position (B4), there will be no signal and running).
3. The sketch of signal test: Please keep the clock power on “ON” position(B4)



II. Calendar setting:


1. Please turn off the device (B4) before the adjustment of calendar
2. Please adjust time according to above process.
3. The sequence of calendar setting: week → date → month.
 - 1) The adjustment of week: please circumvolve the knob (B3) as indicated. (don't circumvolve the knob in reverse)
 - 2) The adjustment of date: please turn on date switch (B2), then the date will be automatically flipped. When the correct date displays, please turn off date switch (B2) immediately to avoid flipping to next date. If the date has flipped to next date, please adjust it again.
 - 3) The adjustment of month: please circumvolve the knob (B1) as indicated. (don't circumvolve the knob in reverse)
4. Please turn on the device (B4) after you finish the adjustment.
5. Under leap year (with 29 days in February), the device will display one day earlier than actual date. Please adjust to the correct date in March according to above calendar settings. For example: Please adjust the date to 1st, March when the device displays 2nd, March.
6. 2000-2099 year setting
There are in total 20 pieces of numbers in numbers compartment (C4).
 - 1) 3pcs of “2”
 - 2) 3pcs of “0”

3) 2pcs of each “1, 3, 4, 5, 6, 7, 8”

4) share number “6”and”9”

Please replace on 1st, January every year.

7. The sketch of signal test:



III. Battery (excluded)

1. Please insert battery in the right direction as indicated.

2. Battery information:

a) Calendar Part(C2): SIZE”C”(UM-2) X 2PCS

b) Time movement part(C1): SIZE”AA”(UM-3) X 1PC

3. Please change new batteries if the hands move slowly or calendar stops working.

4. Please use alkaline batteries and do not mix old batteries with new ones.